



Pitching Instructions – Atlas 200 & 300

Inner First Pitching

- Assemble the 2 long poles and lay them parallel on the ground.
- Open out inner and position in required direction.
- Insert the two longer poles diagonally through pole sleeves on inner tent.
- Locate one end of each diagonal pole onto pin system at groundsheet corners (see figure 1).
- Push each diagonal pole into an arch from opposite end and locate pole ends onto corresponding pin system.
- Attach all clips that connect inner tent to poles.
- Peg each of the 4 corners of the inner tent through the ring, of the ring and pin system (see figure 2).




Figure 1.




Figure 2.

Flysheet

- Open out flysheet and position over the inner tent so the doors correspond.
- Pull flysheet over the inner tent and position seams to correspond with poles on inner.
- **A number of velcro strips are located on the underside of the flysheet. These must be wrapped around the poles of the inner tent.**
- Peg down each side of flysheet through the shock-cord pegging points, adjacent to the metal rings of the inner tent. Use the pin-pegs supplied.
- Peg out all remaining shock-cord pegging points on the base of the flysheet using pin-pegs.
- Peg out **ALL** guy lines using pin-pegs ensuring that guy line fabric attachment points are evenly tensioned.

Ring and Pin System.

1. Locate one end of each pole onto the corresponding metal pin. The metal pin inserts into the hollow metal ferrule on the end of each pole. **(See Figure 1)**. Push the pole into a curve from the opposite side, one at a time, and locate all pole ends onto the metal pins.
2. Peg the corners of the tent through the metal rings using pin-pegs. It is important to drive the peg into the ground at a 45 degree angle to obtain the best grip. **(See Figure 2)**.

IF YOU HAVE ANY PROBLEMS PLEASE CONTACT YOUR LOCAL RETAILER or
AMG Group Ltd., Kelburn Business Park, Port Glasgow, Scotland. PA14 6TD.
UK Consumer Hotline: 0844 811 0535 E-Mail: info@vango.co.uk

Calls to our Customer Hotline cost 5p per minute. Calls from mobile phones, cable networks or public payphones will generally cost more.