



Pitching Instructions – Adventure Windbreak

- Assemble the 3 steel uprights from the sections provided. Each upright pole comprises 3 sections.
- Each pole should have a short pin at the bottom & a long pin at the top (To attach the guy line to)
- Insert the poles into the sleeves of the windbreak & secure with rings attached.
- Starting at one end of the windbreak attach 2 guy lines to the top of the pole & peg out at around 90 degrees from each other, as diagram below.
- Now move to the other end of the windbreak & again use 2 guy lines at 90 degrees.
- Tension the windbreak further by pegging out the remaining uprights, as shown below.

Caution:

The windbreak is not designed for very high wind speeds or very exposed campsites.

