



Pitching Instructions – Sungari Sun Canopy

Pitching Instructions

- Assemble the poles & insert into colour coded sleeves.
- Locate one end of the pole in ring & pin system as **Figure 1** below.
- Push poles into an arch from opposite side and locate other pole end on to corresponding pin system on flysheet.
- Tension the webbing strap at the pole end.
- Position the fabric end of canopy towards tent.
- Secure in position by attaching the top webbing strap pole clips to the second pole of the tent and the lower webbing strap pole clips to the first pole of the tent.
- Secure in position by pegging out the guy lines.
- Peg out the front of the canopy to tension the material.
- Peg out **ALL** peg points including rings as **figure 2**, and peg out **ALL** guy lines.

The Vango Sungari Canopy is designed for use in lowland sheltered campsites. Do not pitch in high winds or exposed campsites.




Figure 1.




Figure 2.