



Pitching Instructions - Tunnel Extension

Pitching Instructions

- Assemble the poles; 4 steel uprights and 2 steel curved roof poles.
- Insert the curved roof poles through the sleeves on the extension.
- Attach the upright poles to the roof poles.
- Locate one end of the pole in ring & pin system as **Figure 1** below.
- Stand the canopy upright and locate other pole end on to corresponding pin system on flysheet.
- Tension the webbing strap at the pole end, and attach pole clips to poles.
- Position the fabric end of canopy towards the side door of the tent.
- Secure in position by attaching the guy line to the ground on the opposite side of the tent.
- Peg out the front of the canopy to tension the material.
- Peg out **ALL** peg points including rings as **figure 2**, and peg out **ALL** guy lines.

The Vango Tunnel Canopy is designed for use in lowland sheltered campsites. Do not pitch in high winds or exposed campsites.




Figure 1.




Figure 2.