Pitching Instructions – Icarus Sun Canopy

Pitching Instructions

- Assemble the poles & insert into colour coded sleeves.
- Locate one end of the pole in ring & pin system as **Figure 1** below.
- Push poles into an arch from opposite side and locate other pole end on to corresponding pin system on flysheet.
- Tension the webbing strap at the pole end.
- Position the fabric end of canopy towards tent.
- Secure in position by attaching the top webbing strap pole clips to the second pole of the tent and the lower webbing strap pole clips to the first pole of the tent.
- Secure in position by pegging out the guy lines.
- Peg out the front of the canopy to tension the material.
- Peg out **ALL** peg points including rings as **figure 2**, and peg out **ALL** guy lines.

The Vango Icarus Canopy is designed for use in lowland sheltered campsites.
Do not pitch in high winds or exposed campsites.



Figure 1.



Figure 2.

IF YOU HAVE ANY PROBLEMS PLEASE CONTACT YOUR LOCAL RETAILER or
AMG Group Ltd., Kelburn Business Park, Port Glasgow, Scotland. PA14 6TD.
UK Consumer Hotline: 0844 811 0535 E-Mail: info@vango.co.uk
Calls to our Customer Hotline cost 5p per minute. Calls from mobile phones, cable networks or public payphones will generally cost more.